DIALATRON MODEL TRIMTRONIC 10



OPERATING INSTRUCTIONS





CONGRATULATIONS

You are now the owner of a totally electronic auto-dialling telephone offering you the same features as your existing telephone plus much much more.

Manufactured by Dialatron and approved by the British Approvals Board for Telecommunications to the highest quality and precise standards.

This loop-disconnect telephone can be connected to the Public Switched Telephone Network but not used as an extension to a payphone or party-line.

Your Dialatron telephone is fitted with a standard jack plug and therefore can be moved around the home or office. Contact your nearest British Telecom sales office and arrange for the socket system to be installed, their telephone number can be found in the front of your telephone directory.

REN

Your Dialatron telephone has a Ringer Equivalence Number (REN) of 1.5. To determine the maximum number of telephone apparatus that can be connected to your exchange line simply add together the individual REN's of all the apparatus you wish to connect, including the B.T. telephone which has a REN of one unless otherwise marked. If this total exceeds four your telephones may not ring correctly.

RINGER SWITCH ON/OFF

To receive incoming calls switch to the 'ON' position. However, if you do not want to be disturbed, switch to the 'OFF' position; this will not affect your ability to make outgoing calls.

DIALLING

To make a call, lift the handset, listen to dial tone, then press the appropriate buttons of the number you are dialling. If you wish to make several calls in succession, just press and release the DIAL TONE RESET BUTTON for two seconds, and then continue dialling, you need not replace the telephone.

REDIAL BUTTON (#)

The (#) button performs the last number redial function by automatically storing and transmitting the last number dialled (up to twenty two digits). Simply press and release the DIAL TONE RESET BUTTON for two seconds as before, listen to dial tone then press and release twice the (#) button.

MEMORY BUTTON (*)

Your telephone can store 10 telephone numbers of up to 18 digits each in its internal memory without any external power source or battery, its unique circuit provides power from the telephone line only. The 10 telephone numbers are stored in memory locations identified by the buttons (1) to (0) on the keypad.

To store a new number or change an existing number in memory:-

- 1. Press and release the (*) button.
- 2. Enter the number you wish to store.
- 3. Press and release the (*) button.
- 4. Enter the memory location (1) to (0).

Example; to store 01-234-5678 in memory location 3 press and release consecutively (*) (0) (1) (2) (3) (4) (5) (6) (7) (8) (*) (3)

Repeat steps 1 to 4 and store all your friends telephone numbers in different memory locations. If the number is larger than 18 digits divide the number and store it in two locations.

To dial a number from memory: -

- 1. Lift the telephone and listen for dial tone.
- 2. Press and release the (#) button.
- 3. Press and release the memory location button (1) to (0).

Example; to automatically dial a number stored in memory location 3, listen to dial tone then press and release consecutively (#) (3).

Keep a list of your programmed telephone numbers-

NAME	NUMBERS
1.	
2.	
3.	
4.	
5.	
6.	
7.	
8.	
9.	
0.	

HOW TO KEEP YOUR TELEPHONE IN GOOD OPERATING CONDITION

- Do not install your telephone in hot or humid conditions.
- Do not place your telephone in direct sunlight.
- Do not spray with aerosol polishes as they may enter the holes in your telephone and cause damage.
- To clean, wipe with damp cloth.

SERVICE

In the event of your telephone failing to perform properly: Check whether it is the telephone or the exchange line causing the problem by unplugging all extension telephones, plugging your Dialatron telephone into the master socket and contacting the B.T. telephone engineer.

Your Dialatron telephone is fully guaranteed for 12 months providing the seal is not broken and it is not damaged by misuse or negligence.

In order that we may deal quickly with requests for service, either under guarantee or at a later stage, please fill in and return the Customer Registration Card without delay. PLEASE KEEP THE ORIGINAL PACKING MATERIAL. If it is necessary to return the telephone to us, please enclose, with your name and address, a remittance of ± 2.50 made payable to 'Phonemend' to cover return delivery and handling.

The guarantee does not cover damage by misuse or excessive voltages; for example, faults on the British Telecom line, or lightning.

The address to send your telephone to is:

Dialatron 42A Hill Street Kingswood BRISTOL BS15 4ES

Telephone number: Bristol (0272) 602066