

EXTENSION PLAN 107 & 107A

AUTO SYSTEM INTERNAL AND EXTERNAL

EXTENSION





TELECOMMS
HQRS

PAPER:- W

DISTN:GENERAL

C NEW FORMAT EXTENSION TELE. CHANGED. MINOR AMENDMENTS. D.L.F. TD 7:1:1 22:10:75

B REVISED FORM NOTES AMENDED. M.B.M. 14:6:65

EXTENSION PLANS 107 & 107A CONSIST OF A MAIN TELEPHONE WITH A PRESS KEY SWITCHING UNIT AND ONE EXTENSION (INTERNAL OR EXTERNAL) WITH INTERCOMMUNICATION.

FACILITIES :-

INCOMING CALLS ARE NORMALLY RECEIVED AT MAIN, BUT THEY MAY BE RECEIVED AT EXTENSION IF SO DESIRED.

EXCHANGE CALLS FROM MAIN CANNOT BE HEARD . EXTENSION.

EXTENSION TO EXCHANGE CALLS ARE NOT SECRET FROM MAIN ON PLAN 107 BUT ARE SECRET ON PLAN 107A.

THE MAIN CAN HOLD AN EXCHANGE CALL AND SPEAK TO THE EXTENSION WITHOUT BEING HEARD ON THE EXCHANGE LINE.

A WHITE LAMP AT THE MAIN SHOWS WHEN THE EXCHANGE LINE IS IN USE BY THE EXTENSION:

A RED LAMP AT THE MAIN SHOWS WHEN THE EXCHANGE LINE IS BEING HELD.

PRESS KEY SIGNALLING IS PROVIDED BOTHWAYS BETWEEN THE MAIN AND THE EXTENSION (WHETHER THIS IS INTERNAL OR EXTERNAL), BUT ONCE A CALL HAS BEEN SET UP BETWEEN AN EXTERNAL EXTENSION AND THE EXCHANGE (IN EITHER DIRECTION) THE MAIN CANNOT BE CALLED IN BY THE EXTENSION

WITH THE EXTENSION SWITCHED THROUGH TO THE EXCHANGE, INCOMING CALLS RINGING THE EXTENSION TELEPHONE BELL ARE ALSO INDICATED TO THE MAIN BY A BELL IF THE EXTENSION IS INTERNAL, OR BY A BUZZER IF EXTERNAL

THE MAIN CALLS AN EXTENSION BY BUZZER IF INTERNAL AND BY BELL IF EXTERNAL.

OTHER REFERENCES :

TELECOMMUNICATIONS INSTRUCTION B MARKETING COMMERCIAL
4 FACILITIES & APPARATUS
C 0018