

CB & AUTOMATIC SYSTEMS
SUBSCRIBER'S EXTENSION PLAN I (INTERNAL ONLY)
ON INTERNAL EXTENSION OF PLAN 7 OR 7A
USING TELEPHONES Nos. 326 CB & 328...

N.4331
 2 PANELS-1
 20-8-54

NOTES.

GENERAL

1. THE DIAGRAM SHOWS A PLAN I EXTENSION CONNECTED TO THE INTERNAL EXTENSION OF A PLAN 7 OR 7A, THIS CAN BE USED IN CONJUNCTION WITH DGM. N 4309 PANELS 2, 3 & 5 OR DGM. N 4310 PANELS 2, 3 & 5.
2. FOR AUTOMATIC WORKING USE APPROPRIATE TELEPHONE.
 eg. TELEPHONE No. 328 F.
 REMOVE STRAP DS4-DS5 IN TELE. No. 326 CB. FIT DIAL AUTO No. 12... & CORD INST. No. 5/28E 5.
PLAN 7 & 7A INTERNAL EXTENSION.
3. WHEN USED WITH DGM. N 4309 PANELS 2, 3 & 5 BELL No. 56D & WIRING SHOWN DOTTED SHOULD BE OMITTED.
4. FIT CORD, INST. No. 6/21B... & BLOCK. TERMINAL No. 20/8 WITH BT4-BT7 STRAPPED, TO TELE. No. 328... FIT KEY 304A WITH TWO PARTS No. 1/SPL/325 (PLUNGERS) IN POSITIONS A&B IN TELE.
 SET LATCH BRACKET CONTROL PLATE OF KEY AS SHOWN ON DGM. N 4301 FIG. 1.
 ADD STRAPS T1-T2-K6 & K1-K9;
 FIT LABEL No. 252 AB ON TELE.
5. PROVIDE 2 CELLS LECLANCHÉ DR2 & CONNECT, WITH 2W CABLE BETWEEN BT4-BT6.

PLAN I EXTENSION.

6. FIT CORD. INST. No. 5/14B... & BLOCK, TERMINAL No. 20/8 TO TELE. No. 326 CB. FIT KEY No. 302A AND CONNECT LEVER SPRING TO T3 & MAKE SPRING TO T1. FIT PART No. 1/SPL/325 (PLUNGER) IN POSITION "B" IN TELE. DISCONNECT STRAPS T10-T11-T12 & CONNECT STRAP BETWEEN T1-T2;
 CONNECT BELL No. 65A COILS IN PARALLEL & FIT LABEL No. 252 E ON TELE.



N 4331
2 PANELS - 2

PLAN 7 OR 7A, INTERNAL EXTENSION

PLAN 1 EXTENSION

