


CIRCULATION	GENERAL
	Suffix
	G
	1483
	121154 F
NOTE 3 AMENDED. TELE. 1/1A ADDED. MADE 5 PANELS SUPERSESSION NOTE ADDED.	
Amendt.	
PAPER	W.

HOUSE EXCHANGE SYSTEM. TELEPHONE, INTERCOM. Nos. 1/1, 1/1A & 1/1AL

QCLD131.
5 PANELS-1.
2-1-36.

NOTES.


1. COMMON BANK CONTACTS ARE OPERATED IN RINGING POSITION OF LOCAL KEYS, i.e. WHEN LOCAL KEYS ARE FULLY DEPRESSED.
2. WHEN EXCHANGE LINE SUPERVISION IS REQUIRED REMOVE STRAP 1-2 AND CONNECT STRAP 2-3.
3. IN TELES. INTERCOM 1/1 & 1/1A DIAL AUTO No. 211A BLACK AND CORD INST. 5/04E ARE REPLACED BY DIAL DUMMY. DS1 & DS2 ARE STRAPPED.
4. EARLY ISSUES OF TELEPHONE, INTERCOM. No. 1/1 WERE FITTED WITH COIL, INDUCTION No. 22 MK.1
5. ADJUSTMENT DETAILS FOR RELAY No. 603 ARE GIVEN IN E.I. TELEPHONES, AUTO. B 5154
6. WHEN LOCAL STATIONS DESIRE TO CALL THE MAIN STATION WHEN THE LATTER IS HOLDING AN EXCHANGE CALL FIT TELEPHONES INTERCOM. No. 1/1A ON MAIN STATION. OMIT STRAP CM1 TO CM2 AND CONNECT STRAP CM2 TO CM3 -ALSO STRAP TAG R TO TAG B OF MAIN STN. IF SPARE.



POSITION OF STRAPS ON TERMINAL
BLOCK OF TELE., INTERCOM No.1/1A.

Q(L)131

5 PANELS - 2
SUPERSEDED BY PANEL 4.






GENERAL

NOTE 3 AMENDED. TELE. 1/1AL ADDED. 14-8-54 G
MADE PANELS SUPERSESSION NOTE ADDED. 23-11-54 F


HOUSE EXCHANGE SYSTEM TELEPHONE, INTERCOM. No. 1/1

Q(L) 131
5 PANELS-3
2-1-36
SUPERSEDED BY PANEL 5



5 PANELS-4

SUPERSEDES PANEL 2.



TELEPHONE, INTERCOM. No. 1/IAL

TO JUNCTION BOX.

Q(L) 131.

5 PANELS 5

2 · 1 · 36

SUPERSEDES PANEL 3.

GENERAL.



NOTE 3 AMENDED. TELE. 1/1AL ADDED 14-8-64 G
MADE 5 PANELS. SUPERSESSION NOTE ADDED. 23-11-54 F

