


Q(L)132  
2 PANELS -1

UNIT, TRANSFER, INTERCOM. No. 1 (MK. 2)  
AS USED AT 1ST. CHOICE MAIN STATION




Q(L) 132  
2 PANELS-2  
2-1-36

# HOUSE EXCHANGE SYSTEM

UNIT, TRANSFER, INTERCOM. No. 1 (MK.2) AS USED AT 2<sup>ND</sup> CHOICE MAIN STATION

CIRCULATION	GENERAL	
	Suffix	
PAPER	1 & 2 CANCELLED. PANELS 3 & 4 MADE 1 & 2	28-4-48
	MINOR AMENDMENTS	
	SUPERSESSION NOTE ADDED	
	MK. 2 ADDED ON NEW PANELS 3 & 4	
Amend.	W	



- NOTES:- (CONTD. FROM PANEL 1)
- WHEN USED ON INSTALLATIONS HAVING A NON-MULTIPLE STATION ADDITIONAL INDICATOR AND CONNECTIONS SHOWN TO BE INSERTED. UNIT, TRANSFER INTERCOM. No. 1A IS FITTED AT 1ST. CHOICE MAIN STATION IN THIS CASE.
  - FOR WIRING SEE Q(L) 142.