

Q.(L)/53.9-5-35

Label No.77A.








MAIN STATION




(O)

When no 2nd Choice main station fitted OR at 2nd choice Main Station on installations without external extension



For use at IST CHOICE MAIN STATION

When 2nd choice main station fitted



For use at 2ND CHOICE MAIN STATION

Button

(0)

on installations with external extension (Unit, Transfer, Intercom No.1A is fitted at 1st Choice Main Stations on these installations see Q (54)

NOTE

A & B are used only on installations with no external extension