

CIRCULATION GENERAL

HOUSE EXCHANGE SYSTEM. UNIT, TRANSFER, INTERCOM, No.3. Q. 156. 9-5-35





MAIN STATION

1ST. CHOICE MAIN STATION. When 2nd Choice

When no 2nd. Choice Main Station fitted.

Main Station Fitted NOTE :- THIS UNIT IS USED AT IST. CHOICE MAIN STATIONS ON INSTALLATIONS WIRED WITH 20PR/10 MULTIPLE CABLE AND HAVING AN EXTERNAL EXTENSION STATION. UNIT TRANSFER INTERCOM. No.1. OR No.2 (ACCORDING TO THE NUMBER OF WORKING EXCHANGE LINES) IS ALSO FITTED AT THE IST. CHOICE MAIN STATION ON

THESE INSTALLATIONS.

