HOUSE EXCHANGE SYSTEM EXPLANATORY ELEMENTS OF ENGAGED EXCHANGE LINE

NOTES:— EXPLANATORY ELEMENTS O

I. MULTIPLE STATION CALLING ENGAGED EXCHANGE
LINE PANEL 2. SHOWS A STATION DEPRESSING

THE EXCHANGE LINE BUTTON OF AN EXCHANGE LINE
ENGAGED BY ANOTHER STATION, EARTH IS RETURNED FROM THE
STATION ENGAGED ON THE EXCHANGE LINE VIA HINZ, MULTIPLE
C WIRE TO OPERATE THE BUZZER OF THE STATION ATTEMPTING
TO PICK UP THE ENGAGED EXCHANGE LINE, THE AN RELAY OF
THIS STATION CANNOT OPERATE AS CONTACT GS AT THE UNIT
TRANSFER HAS REMOVED THE EARTH FROM THE D WIRE OF

2. STATION I. CALLING STATION 2. WHICH IS ENGAGED ON EXCHANGE CALL, AT THE CALLING STATION (PANEL 3.) ON DEPRESSION OF THE LOCAL BUTTON FOR THE REQUIRED STATION EARTH IS EXTENDED VIA THE MULTIPLE BY WIRE & IS RETURNED FROM THE STATION ENGAGED ON AN EXCHANGE CALL VIA IH3 CONTACT, & THE COMMON WIRE TO OPERATE THE BUZZER OF THE CALLING STATION.

3. COMMON BANK IS OPERATED IN RINGING POSITION OF LOCAL

Amendt.

BUTTON.

₹



