



- NOTES:-**
- 1 FUSE 1 SA PER CIRCUIT
 - 2 SHELF JACK POINTS U9-U11, U13-U15 MAKE CONTACT WHEN RELAY SET IS REMOVED
 - 3a WORKING TO CB (40V) STRAP U57-59 & U63-65.
 - 3b WORKING TO CB (22V) STRAP AS IN (c) ALSO STRAP U67-69
 - 3c WORKING TO AUTO WITH DISCONNECT CLEARING STRAP U63-65
 - 3d WORKING TO MAGNETO OR C.B.S. FIT ADAPTOR CCTS SAW 81550 OR SAW.81540 OR EQUIVALENT
 - 4 D RELAY DIFFERENTIALLY CONNECTED.
 - 5 STRAP BETWEEN SHELF JACK POINTS U68-U70 & WIRING SHOWN THUS —|— IS ONLY REQD ON EXCHANGE LINES WHICH ARE PLUGGED THROUGH FOR NIGHT SERVICE.
 - 6 WHEN ENQUIRY FACILITIES ARE NOT PROVIDED STRAP U27 TO EARTH AT U11 TO GIVE OPERATOR RECALL
 - 7 FOR ANCILLARY WORKING SHELF JACK POINT UB IS CONNECTED TO LAMP LIGHTING RELAY WITH WIRING SHOWN THUS THUS —X—
 - 8 Ø FOR WIRING SEE RELEVANT RACK COMMON SERVICES DIAGRAM
 - 9 EXTERNAL WIRING SHOWN THUS —o— IS PROVIDED WHEN EXCH LINE CCT IS ASSOC'D WITH NIGHT SERVICE SWITCHBOARD VIA N/S ACCESS CIRCUIT SAW 81920 OR EQUIV

BATT W U12-R3b-RHc-CRE-MHc-Hc-NSc-STc-LGc-ZRc-CLc-SRc-R4b-R5b-R6b

ETH R U11-CR21-CR3-DI-MHI-HI-ACI-LG21-LG3-ZR21-ZR24-ZR1-ZR3-Z21-Z1-ERI-CL21-SR1-SR6-R9a-TJ10-U59

ETH ETH BAR 20 S.W.G.R (5A) U11

BATT FUSE 20 SWG BK (5B) U12

TO U27 OF N/S ACCESS CCT SAW 81920 OR EQUIV WHEN REQD. SEE NOTE 9.

<input type="checkbox"/> GLOW RELEASE <input checked="" type="checkbox"/> GLOW OPERATE	
EXCHANGE LINE CIRCUIT FOR P.A.B.X. No. 3.	
AMENDMENT PARTICULARS	ISSUE DATE APPROV REF: 9 336
G.P.O. APPROVED AS STANDARD	
G.E.C. TEL WKS. COVENTRY	DRAWN CHECKED WIRING T.D.
SAW. 81581	