CIRCULATION
GENERAL

HOUSE EXCHANGE SYSTEM

Q(L)203 21·6·35

2 PANELS – 1

PLUG & JACK WIRING FOR UNIT, TRANSFER, INTERCOM, No.2. USED AT 1st CHOICE MAIN STATION.



SP – SPARE WIRES TERMINATED
• – SPARE TERMINALS

AMENDMENT	
(L) added to Q.203	2·11·36 A

W

Q(L) 203

2 PANELS – 2

NOTE

CABLE FORMS FOR JACK WIRING FOR UNIT, TRANSFER, INTERCOM., No2 USED AT 1st CHOICE MAIN STATION.

WHEN THE CABLE ENTRY IS TO BE AT POINT B OF THE JACK REFER TO DIMENSIONS ABOVE THE CABLE FORM DIAGRAM
" " " " " " " " " A " " " " " BELOW " " " "



PR 1	WH BL	2	WH OR	3	WH GR	4	WH BR	5	WH SL	6	BL-WH	7	WH OR	8	BL-GR	9	WH BL-BR	10	WH BL SL	11	OR-WH	12	WH OR-GR



CABLE FORM FOR ENTRY AT POINT C

FOR POSITION OF ENTRY POINTS A, B & C AND POSITIONS IN WHICH THE JACK MAY BE PLACED SEE Q204 (NOTE 2)